



TYPE S MORTAR MIX

ProMasonry Type S Mortar Mix exceeds the requirements of ASTM C387 and ASTM C270 for compressive strengths when used as directed.

SUGGESTED USES

- For laying brick, block and stone, or pointing, plastering and stuccoing.

PREPARATION

- Remove all loose and/or deteriorated material as well as any surface contaminants such as oil, paint, grease, etc.

MIXING

- Empty the contents of the bag into a clean wheelbarrow, mortar box, mechanical mixer or other mixing vessel.
- Form a crater with a shovel or hoe in the center of the dry mix. Mix sufficient water to achieve desired workability.
- **For hand mixing** – Blend dry mix with a shovel or hoe from the outer edges working the material towards the center. Continue mixing until all free water is used and all the aggregate is uniformly coated with cement.
- **For mechanical mixing** – Mix the material for three minutes.

FINISHING

- Joints can be finished when material has begun to set and the surface has a thumbprint hard consistency.
- Mortar joints can be finished with a jointing tool.

CURING

- Protect from direct sunlight, wind, rain and frost during the curing period.

CLEAN UP

- Clean tools and equipment with water immediately after use.
- Cured material will need to be mechanically removed.



A Division of
Conproco Corporation

PROMASONRY[®]
PROFESSIONAL QUALITY CEMENT PRODUCTS



TYPE S MORTAR MIX

TECHNICAL DATA

Physical state and appearance		Dry powder with aggregate
Base		Masonry cement
pH	Wet mix	> 12
Aggregate type		Mortar Sand
Compressive Strength @ 28 days		> 1800 psi
Flow	ASTM C230	110% +/- 5%

YIELD

- One 80 lb (36.3 kg) bag will lay up to 65 standard bricks and 26 standard blocks.

CAUTION

- May cause eye and skin irritation.

HEALTH AND SAFETY

- Product is alkaline.
- Do not ingest.
- Avoid breathing dust.
- Avoid contact with skin and eyes.
- Refer to Material Safety Data Sheet (MSDS) for additional information.
- Keep out of reach of children.

FIRST AID

- In case of skin contact, wash thoroughly with soap and water.
- For eye contact, flush immediately with a high volume of water for at least 15 minutes and contact a medical professional.
- For respiratory problems remove person to fresh air.

DISPOSAL

- Dispose of material in accordance with local, state or federal regulations.

MANUFACTURER'S LIMITED WARRANTY

Conproco Corp. warrants this product for one year from date of installation to be free from manufacturing defects and to meet the technical properties on the current technical data sheet if used as directed within shelf life. User determines suitability of product for use and assumes all risks. Buyer's sole remedy shall be limited to the purchase price or replacement of product exclusive of labor or cost of labor. July 2010
NO OTHER WARRANTIES EXPRESS OR IMPLIED SHALL APPLY INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.
CONPROCO CORP. SHALL NOT BE LIABLE UNDER ANY LEGAL THEORY FOR SPECIAL OR CONSEQUENTIAL DAMAGES.

PROMASONRY®

MANUFACTURED BY: **CONPROCO CORPORATION**
PHONE 800.258.3500 FAX 603.743.5744 WEBPROMASONRY.NET